

# FITTING INSTRUCTIONS FOR RANGE ROVER P38 RUBBER STEPS - LATEST DESIGN (L322 STYLE)



1. Fit the four handed brackets to the chassis first with a 10mm spanner. The longer shaped plate goes to the front of the vehicle. The fixing holes are pre-drilled by the factory and are located in the side of the chassis approximately below the centre of each door. Do not tighten bolts fully yet.
2. Now attach the steps to the brackets with bolts provided and a 13mm spanner - use a washer under each nut.
3. Adjust steps for best horizontal fit and tighten bracket fixings from step 1. Now tighten all other nuts and bolts fully.
4. Fit front mudflaps using the screws provided. The top two screws fit through the edge of the wing arch, and the third one goes through the mudflap and self taps into the end of the step. Adjust mudflaps for best fit, re-check all bolts and apply test load. Your steps are now ready.

Note :- Fitting time 15 minutes per side, faster with socket set. Requires 10mm and 13mm spanner/socket. The steps have very little exposed steel and if looked after should last the life of the vehicle.

